



## **DRIVING EVENTS DEFINED**

Idealease revolutionizes fleet operations with ELEVATE™, our proprietary Driver Performance System that improves driver safety and saves fleets millions of dollars in annual operating costs.

Sign up for the ELEVATE™ Question/Tip of the Week and receive short, actionable, and easy-to-use information to help your drivers operate their vehicles more safely while reducing fuel consumption, idle time, wear and tear on equipment, maintenance costs, vehicle downtime, and more.

If you have a question or a topic you would like covered in a future ELEVATE™ Question/Tip of the Week, email <u>jerryring@idealease.com</u> (mailto:jerryring@idealease.com).

Find a complete list of ELEVATE™ topics below.

## **Q:** I noticed driving events (cornering, braking, acceleration) on my scorecard. What triggers these events?

A: The telematics device has an accelerometer inside the device. When this accelerometer detects a .3gForce movement forward, backward, or to the side, it triggers a driving event. Depending on the direction of the force, it will register as a "Brake", "Acceleration", or "Corner".

When working with a driver that has frequent driving events, you want to sit down with them, contact the Idealease Business Intelligence contact who provided the scorecard for an activity report for that

vehicle. The activity report will provide the location and data on where the event happened, along with the speed in which it occurred, which is especially helpful when reviewing these driving events.

24/7 ROADSIDE ASSISTANCE CALL 1-800-435-3273

IDEALEASE, INC.

430 North Rand Road, North Barrington, IL 60010 | **847-304-6000** |