


This Week: Idle Shutdown Ambient Settings



Idle Shutdown Ambient Settings



Q: In extreme weather (hot or cold), there are times when we do not want the vehicle to shut off as part of the Idle Shutdown Timer settings. Can that be done?

A: Yes. All of our vehicles have Cold and Hot Ambient Air Temperature settings. Ambient Temp override is 30 degrees Fahrenheit and 81 degrees Fahrenheit.

If the vehicle reads an ambient temperature outside of those ranges, it will disengage the Idle Shutdown Timer. That is why it's important to coach your drivers on controlling their idle and using the key to shut off their vehicle instead of letting the Idle Shutdown Timer do so. If the truck is outside the above ranges, failure to shut the vehicle off with the key can result in excessive, unwanted idle time.

Idealease is committed to helping your team Elevate their Performance. You will receive a weekly Question or Tip of the Week explaining different elements of the scorecard, tips to improve Key Performance Indicators (KPI's), or other motivational topics to keep the team (s) striving for excellence behind the wheel. If you have a question or would like a topic covered, please email jerryring@idealease.com.



Mailing Address:
430 North Rand Road
North Barrington, IL 60010



Copyright © 2019, All rights reserved.

ELEVATE: QUESTION/TIP OF THE WEEK SIGNUP

Email *

First Name *

Last Name *

Job Title *

Company *

SUBMIT

[Click Here To Register](#)

[update subscription preferences](#)

Is this email not displaying correctly?
[View it in your browser.](#)