

IDEALEASE



WHAT DOES PTO HOURS STAND FOR?

Idealease revolutionizes fleet operations with ELEVATE®, our proprietary Driver Performance System that improves driver safety and saves fleets millions of dollars in annual operating costs.

Sign up for the ELEVATE® Question/Tip of the Week and receive short, actionable, and easy-to-use information to help your drivers operate their vehicles more safely while reducing fuel consumption, idle time, wear and tear on equipment, maintenance costs, vehicle downtime, and more.

If you have a question or a topic you would like covered in a future ELEVATE Question/Tip of the Week, email ELEVATE@Idealease.com (<mailto:ELEVATE@Idealease.com>).

Find a complete list of ELEVATE topics below.

Q: Can you explain what PTO stands for? I see "PTO Hours" mentioned regularly in my ELEVATE® scorecard.

A: "PTO" stands for Power Take-Off, which is a transmission function option on all Idealease vehicles. It transfers the power of the vehicle's engine to operate auxiliary components on the vehicle. Common examples of operating these auxiliary components are hydraulic pumps for dump bodies, wet kits, etc.

If you do not have a PTO function on the truck, this is a clear indicator that the operator of the vehicle is over-riding the Idle Shutdown Timer to intentionally keep the truck running for one reason or another. PTO idling is inefficient, and costly. It can cause more frequent regenerations, as well as unproductive fuel burn.

24/7 ROADSIDE ASSISTANCE
CALL 1-800-435-3273

IDEALEASE, INC.
430 North Rand Road, North Barrington, IL 60010 | **847-304-6000** |