



## HOW IS IDLE TIME CALCULATED

Idealease revolutionizes fleet operations with ELEVATE™, our proprietary Driver Performance System that improves driver safety and saves fleets millions of dollars in annual operating costs.

Sign up for the ELEVATE™ Question/Tip of the Week and receive short, actionable, and easy-to-use information to help your drivers operate their vehicles more safely while reducing fuel consumption, idle time, wear and tear on equipment, maintenance costs, vehicle downtime, and more.

If you have a question or a topic you would like covered in a future ELEVATE™ Question/Tip of the Week, email [jerryring@idealease.com](mailto:jerryring@idealease.com) (<mailto:jerryring@idealease.com>).

Find a complete list of ELEVATE™ topics below.

### **Q: Can you explain how Idle Time is calculated?**

**A:** The ECM transmits engine hours to the telematics device, which provides Total Engine Hours, Total Idle hours, and Total PTO hours. In the scorecard, we calculate the Idle % by dividing the Idle Hours by the Total Engine Hours.

$1.65 \text{ Engine Idle Hours} / 22.3 \text{ Total Engine Hours} = 7.4\% \text{ Idle}$

It is important to note many of our vehicles do not have a PTO function, but it is possible to register PTO hours reported in the scorecard. Those hours will be added to the engine idle hours to produce a True engine idle %.

You will see more on the PTO hours in a future weekly email.

---

**24/7** ROADSIDE ASSISTANCE  
CALL 1-800-435-3273

**IDEALEASE, INC.**  
430 North Rand Road, North Barrington, IL 60010 | **847-304-6000** |